

Lesson 2.6: Principal Stresses and Failure Criteria Analysis



Modified: Aug. 2, 2026

Published: Sep. 17, 2025



Become Contributor

Expert Support

Real components rarely experience pure tension, pure bending, or pure torsion in isolation. A robotic joint shaft bends and twists simultaneously; a bracket carries tension on one face and compression on the other along with shear. Checking each

stress component individually against the yield strength gives a false sense of safety because the combination of stresses can cause failure at levels well below the individual limits. Mohr's circle and failure theories (von Mises, Tresca, maximum normal stress) provide the framework for combining these stresses into a single safety assessment. In this lesson you will construct Mohr's circle, find principal stresses, and apply failure criteria to predict whether a mechatronic joint will survive its combined loading. #PrincipalStress #MohrsCircle #FailureAnalysis

> **Try it as you read**
>
> This lesson pairs with the Mohr's Circle Simulator: rotate a stress element and watch its face stresses ride around the circle, then work the six Stress Transformation Experiments for Python-verified practice.

Learning Objectives

By the end of this lesson, you will be able to:

1. **Construct** Mohr's circle for any 2D stress state in mechatronic components
2. **Determine** principal stresses and maximum shear stresses graphically and analytically
3. **Apply** appropriate failure theories for different materials and loading conditions
4. **Predict** failure modes in complex mechatronic joint designs

Real-World System Problem: Universal Joint in Robotic Drive System

Universal joints in robotic drive trains experience complex 3D stress states from transmitted torque, bending moments, and contact forces. Understanding principal stress distributions and applying appropriate failure criteria is essential for preventing catastrophic failures in critical robotic applications.

System Description

Robotic Universal Joint Components:

- **Cross Pin** (transmits torque between intersecting shafts)
- **Bearing Races** (allow rotation while constraining radial motion)
- **Fork Arms** (connect to input and output shafts)
- **Needle Bearings** (reduce friction in oscillating motion)
- **Sealing System** (protects against contamination)

The Complex Stress Challenge

During robotic operation, the universal joint pin experiences:

> **Multi-Dimensional Stress State**
>
> - **Torsional shear** from transmitted torque (τ_{xy}, τ_{xz})
> - **Bending stresses** from joint angulation (σ_x, σ_y)
> - **Contact stresses** at bearing interfaces (localized σ and τ)
> - **Fatigue loading** from oscillating joint angles
> - **Stress concentrations** at pin diameter changes and keyways

> **Engineering Question:** How do we determine the critical stress state in a universal joint pin that experiences 500 N·m torque, 200 N·m bending moment, and bearing contact forces, and predict which failure mode is most likely to occur?

Why Principal Stress Analysis Matters

Consequences of Inadequate Stress Analysis:

- **Unexpected joint failure** during critical operations
- **Catastrophic system shutdown** from drive train failure
- **Safety hazards** in human-robot collaborative environments
- **Expensive repairs** and extended downtime
- **Loss of system reliability** and customer confidence

Benefits of Comprehensive Stress Analysis:

- **Accurate failure prediction** under complex loading
- **Optimized joint geometry** for maximum reliability
- **Material selection** based on actual stress states
- **Preventive maintenance** scheduling based on stress analysis

Fundamental Theory: Principal Stress Analysis

The General Stress State

At any point in a stressed body, the stress state can be described by:

2D Stress Components:

- Normal stresses: σ_x, σ_y
- Shear stress: τ_{xy} (= τ_{yx})

3D Stress Components:

- Normal stresses: σ_x, σ_y, σ_z
- Shear stresses: τ_{xy}, τ_{yz}, τ_{zx}

Principal Stress Theory

Principal Stress Equations | Maximum Shear Stress | 3D Stress State

Principal Stress Equations

For 2D stress state: $\sigma_{1,2} = \frac{\sigma_x + \sigma_y}{2} \pm \sqrt{\left(\frac{\sigma_x - \sigma_y}{2}\right)^2 + \tau_{xy}^2}$

Principal angles: $\tan(2\theta_p) = \frac{2\tau_{xy}}{\sigma_x - \sigma_y}$

Where:

- σ_1, σ_2 = Principal stresses (Pa)
- σ_x, σ_y = Normal stresses on coordinate planes (Pa)
- τ_{xy} = Shear stress on coordinate planes (Pa)
- θ_p = Orientation of principal planes (degrees)

Physical Meaning: Principal stresses are the maximum and minimum normal stresses at a point, occurring on planes with zero shear stress.

Mohr’s Circle Construction

Mohr’s circle provides a graphical method for stress transformation:

Mohr's Circle Parameters

Circle Center: $C = \left(\frac{\sigma_x + \sigma_y}{2}, 0\right)$

Circle Radius: $R = \sqrt{\left(\frac{\sigma_x - \sigma_y}{2}\right)^2 + \tau_{xy}^2}$

Physical Meaning: Mohr's circle graphically represents all possible stress states at a point as the coordinate system is rotated. The circle's diameter equals the difference between principal stresses.

Key Points on Circle:

- Principal stresses: σ_1 and σ_2 (intersections with σ-axis)
- Maximum shear: τ_{max} (top and bottom of circle)
- Any stress state: Point on circle circumference

> **Mohr's Circle Applications**
>
> 1. **Find principal stresses** graphically
> 2. **Determine stress at any angle** of rotation
> 3. **Visualize stress transformation** relationships
> 4. **Identify critical orientations** for failure analysis

Constructing the circle by hand for every state is slow, and the link between the rotating element and the moving point is exactly what gets lost on paper. Open the interactive tool and drag the element through its rotation while the circle, the principal stresses, and the safety factor update live:

Open the Mohr's Circle Simulator

Application: Universal Joint Pin Analysis

Let’s analyze a critical universal joint pin under complex loading.

> **Problem Statement**
>
> **Heavy-Duty Robotic Universal Joint Pin Analysis**
>
> **What we need to determine:**
>
> 1. **Individual stress components** from bending, torsion, and contact loading
> 2. **Principal stresses** using analytical methods and Mohr’s circle
> 3. **Critical failure modes** using multiple failure theories
> 4. **Design adequacy** and required modifications for safe operation
>
> **Key Question:** Can a 25 mm diameter universal joint pin safely handle 500 N·m torque and 200 N·m bending with SF = 4, and which failure theory governs the design?

System Parameters:

- Heavy-duty robotic universal joint pin (critical drive component)
- Pin diameter: 25 mm (solid circular cross-section)
- Material: Steel 4340 (`σ_yield` = 470 MPa, σ_ultimate = 745 MPa)
- Applied torque: `T` = 500 N·m
- Bending moment: `M` = 200 N·m (from joint angulation)
- Contact pressure: 50 MPa (localized bearing load)
- `Safety factor`: 4 (industrial environment)

Step 1: Calculate Individual Stress Components

> **Click to reveal individual stress component calculations**


Step 2: Principal Stress Analysis Using Mohr’s Circle

> **Click to reveal Mohr’s circle and principal stress calculations**

Step 3: Apply Failure Theories and Design Assessment

> **Click to reveal failure theory analysis**

Engineering Problems



Problem 1: Pressure Vessel Joint Analysis

A spherical pressure vessel joint experiences complex stress states from internal pressure and thermal effects, requiring principal stress analysis.

Given:

- Spherical pressure vessel: inner radius R = 500 mm, wall thickness t = 20 mm

- Internal pressure: p = 2.5 MPa
- Additional thermal stress: σ_thermal = 50 MPa (tangential direction)
- Material: Steel (σ_yield = 250 MPa, σ_ultimate = 400 MPa)
- Safety factor required: 3.0

Find: Principal stresses and safety factor using von Mises criterion.

> **Click to reveal solution**

Problem 2: Shaft with Keyway Under Combined Loading

A motor shaft with a keyway experiences combined bending and torsion, creating a complex stress state requiring Mohr's circle analysis.

Given:

- Solid circular shaft: diameter d = 50 mm
- Keyway: 12 mm wide × 6 mm deep (standard)
- Bending moment: M = 800 N·m
- Torque: T = 1200 N·m
- Material: Steel 4140 (σ_yield = 415 MPa)
- Stress concentration factor for keyway: Kt = 2.5

Find: Principal stresses at keyway location and safety factor.

> **Click to reveal solution**

Problem 3: Bolted Joint Under Eccentric Loading

A bolted connection experiences eccentric loading creating non-uniform stress distribution requiring principal stress analysis for the most critical bolt.

Given:

- Bolt material: Steel Grade 8.8 (σ_yield = 640 MPa)
- Bolt diameter: M12 (nominal diameter 12 mm)

- Tensile load: F = 8000 N (eccentric, creates additional bending)
- Bending moment on bolt: M = 96 N·m (from load eccentricity)
- Thread stress concentration: Kt = 3.0
- Safety factor required: 4.0

Find: Principal stresses in bolt and design adequacy.

> **Click to reveal solution**

> **Instrument it**
>
> The principal stresses that decide whether a part survives are exactly what a strain-gauge rosette measures. Bond a 0/45/90 rosette to the free surface at the critical point; from its three strains you compute the principal strains, their direction, and through Hooke's law the principal stresses that feed von Mises or Tresca. An ESP32 or STM32 sampling the three channels can track the principal stress and its safety factor on siliconwit.io and warn before the state reaches the yield envelope.

Course Completion Summary

Congratulations! You have completed Mechanics of Materials I & II with a comprehensive systems-based approach.

Knowledge Mastered

Part I: Foundations (Units 1.1-1.6)

- ✅ Stress and strain fundamentals through crank-slider mechanisms
- ✅ Material behavior analysis in CNC actuator systems
- ✅ Multi-material compound systems in linear actuators
- ✅ Thermal stress effects in heated piston-cylinder interfaces
- ✅ Torsional analysis in Geneva mechanism crankshafts
- ✅ Pressure vessel design for pneumatic actuator systems

Part II: Bending & Complex Loading (Units 2.1-2.6)

- ✅ Shear force and bending moment analysis in robotic arms
- ✅ Bending stress calculations in cantilever gripper systems
- ✅ Beam deflection prediction for precision CNC spindles
- ✅ Combined loading analysis in robotic wrist joints
- ✅ Composite beam behavior in CNC machine structures
- ✅ Principal stress analysis and failure prediction in universal joints

Professional Competencies Developed

🚀 Systems Integration

Connect solid mechanics theory to real mechatronic applications **Design** components that function reliably in complex systems Industry-ready skills

Failure Prevention

Predict failure modes before they occur in operation **Apply** appropriate safety factors for reliable design Risk mitigation expertise

Optimization Thinking

Balance strength, weight, cost, and performance requirements **Iterate** designs based on comprehensive stress analysis Design optimization

Your Next Steps

Apply this knowledge to:

- Advanced mechatronics projects requiring structural analysis
- Multi-physics simulations combining stress, thermal, and dynamic effects
- Failure analysis investigations in existing systems
- Design optimization projects balancing multiple objectives

You are now equipped with the solid mechanics foundation essential for successful mechatronic system design and analysis!

Comments

Loading comments...

© 2021-2026 SiliconWit®. All rights reserved.

Previous
Lesson 2.5: Composite and Built-up Beam Systems

Next
Lab: Stress Transformation Experiments

Privacy · Cookie settings